



CONSULT WITH LOCAL ENGINEER IF NEEDED

USE W.W.F. OR REINF. AS REQ'D BY LOCAL CONDITIONS

SLOPE ON CONCRETE IS IMPORTANT FOR DRAINAGE, BUT TOO MUCH SLOPE WILL CAUSE SKATING TO BE DIFFICULT;

THEREFORE WE RECOMMEND A SLOPE OF  $\frac{1}{2}\%$  MAX.

EXPANSION JOINTS - FILL WITH SIKAFLEX CAULK OR EQUAL

SAW CUT NOT TO EXCEED 200 SQ.FT.  $\frac{1}{8}$ " WIDE X  $\frac{1}{8}$ " DEEP (MIN)

FINISH WITH A STEEL TROWEL - VERY SMOOTH

CONCRETE PAD TYPICAL SECTION

4000 PSI (MIN MIX)